

---

**Widerstandstabelle für Fernfühler 1302 00**

---

<b>Temperatur (°C)</b>	<b>Widerstand (Ohm)</b>	<b>Temperatur (°C)</b>	<b>Widerstand (Ohm)</b>
0	1592	31	2051
1	1605	32	2067
2	1619	33	2083
3	1633	34	2099
4	1647	35	2115
5	1661	36	2131
6	1675	37	2148
7	1689	38	2164
8	1703	39	2181
9	1717	40	2197
10	1732	41	2214
11	1746	42	2231
12	1761	43	2248
13	1775	44	2265
14	1790	45	2282
15	1805	46	2299
16	1819	47	2316
17	1834	48	2333
18	1849	49	2351
19	1864	50	2368
20	1879	51	2385
21	1895	52	2403
22	1910	53	2421
23	1925	54	2438
24	1941	55	2456
25	1956	56	2474
26	1972	57	2492
27	1987	58	2510
28	2003	59	2528
29	2019	60	2546
30	2035		

---